


kopos.com





item number	diameter - D (mm)	length - L (mm)	drilling depth (mm)	screw diameter (mm)	package bag/carton (pcs)
HM 6_XX	6	30	35	3,5-4	100/14000
HM 8/1_XX	8	40	45	4-5	100/6000
HM 10_XX	10	50	55	5-6	100/3000
HM 12_XX	12	60	65	6-7	100/2000

material: polyamide

halogen-free: yes

temperature resistance: -30 - +80 °C

storage: ČSN 64 0090

product Designed for light anchoring – fixing of non-structural building components and building equipment to brickwork, concrete and other building materials

Recommendation: wall plugs should be installed immediately after unpacking from the sealed bag. This will prevent needless reduction in the level of humidity PA, which would result in a reduction of the wall plug quality.

installation instructions:

Drill a hole, the drill bit has the same diameter as the diameter of the dowel, hole depth is at least the length of the dowel.

Dowel is inserted into a drilled hole.

Install the screw into the dowel, the dowel is extended and anchored to the wall. The diameter of the screw is shown in table. The length of the screw is the same as the dowel length plus the thicknes of the fastened object.